


15 GAL. ECO TANK EM15 / EH15



Hardware:

Qty	Description
1	1/2" NPT Nipple SS
1	1/2" Ball Valve SS
1	1/2" NPT Barbed fitting SS
1	5/32 Hex Wrench
1	Mounting plate SS with .88 center hole
1	6-Bolt Flange Gasket
6	#10 SAE Flat Washer SS
6	10-24 x 5/8 Socket Cap Screw SS
1	Silicone gasket for 2" NPT nipple
1	1/2" NPT SS Welded flange
2	3/4" SAE Flat Washer SS
1	Silicone Gasket 70D 1/2 NPT



Tools Required:


- 1) 1" wrench and a 1-1/2" crescent wrench.
- 2) Teflon tape

Instructions:

- 1) Wrap the threads of the 1/2" NPT welded flange twice with the Teflon tape clockwise.
- 2) Wrap the threads of the 1/2" NPT SS barbed fitting clockwise twice with Teflon tape.
- 3) Install the 1/2" NPT barbed fitting into the front end of the 1/2" ball valve.





- 4) Install the white silicone gasket into the 1/2" NPT welded flange.



- 5) Install the 1/2" NPT welded flange through the mounting plate with the .88 center hole.
- 6) Install one 3/4" SAE Flat Washer SS through the threads, then the orange silicone gasket and then the second 3/4" SAE Flat Washer SS.
- 7) Thread the 1/2" welded flange into the 1/2" valve. **Make sure the valve handle is centered between any two bolt holes** in the plate, as shown. Use a 1" wrench on the valve and a crescent wrench on the nut.

Handle MUST BE Centered



- 8) Install the valve on the tank using the six 10-24 x 5/8 SS socket cap screw and #10 SS washers. Start all the screws by hand and then tighten using the 5/32 hex wrench in a crisscross pattern.

DO NOT EXCEED 40 IN/LBS IN TORQUE, BRASS INSERTS MAY BREAK LOOSE FROM PLASTIC